



MAMMOTH
office products

HOW TO UNROLL YOUR PVC CHAIR MAT

Mammoth often ships PVC chair mats in a rolled format for ease of delivery and handling.

It may be difficult to unroll the chair mat when cold, because of the “memory” characteristic of the material used. Follow the procedure below to unroll your chair mat:

1. Unpack your mat and leave in a warm location before attempting to unroll.
2. Once it has reached room temperature, carefully unroll the mat placing it on a flat surface with the “bow” facing upward.
3. You may add weight to the corners, if necessary.* It may take up to 72 hours for the mat to regain its normal flat format, depending on the environmental temperature.

* Avoid placing weights on the grippers on the mats for carpet applications.

