



ASSEMBLY INSTRUCTIONS


Remove all items from the carton . Verify all pieces before assembly.

PARTS LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	12	2	Mechanism Bracket
2	1	Base	8	2	Armrest	12	J	Screw 8x20mm + Washer
3	1	Seat Post	9	2	Arm Width Adjustment	13	1	Backrest Screw 8x10mm
4	1	Seat Post Cover			Knob + Washer	14	1	Backrest Post
5	1	Mechanism	10	2	Arm Bracket			
6	1	Seat	11	1	M5 Size Allen Wrench			







If the up/down operation of the ratchet back feels tight, raise and lower the back several times after assembling the chair to insure smooth functioning. **MECHANISM INSTRUCTIONS:** (A) SEAT HEIGHT ADJUSTMENT: Pull lever up and downward. Release Œ lever when desired position is reached. (B) BACK TILT ADJUSTMENT: Pull lever horizontally. Move backrest to tilt. To lock in upright position, push lever in. TILT TENSION ADJUSTMENT KNOB: Rotate knob clockwise / counterclockwise to adjust tilt tension based on body weight.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME. DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER. DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT. DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES. DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHTENED.
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OFTHE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS. DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY, DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. NOTE:SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS ASSEMBLY INSTRUCTIONS.